


## INSTRUCTIONS:

1. HERE ARE SOME INSTRUCTION
2. POINTERS NEEDED FOR THE INSTALLATION OF THE DOOR TO THE HOUSING.
3. ONCE THE FIXTURE HOUSING INSTALLED IN PLACE WITH SUITABLE FRAMING, REMOVE THE HINGE LOCK NUTS WHICH ARE ON THE HOUSING. (WE ALSO SHIPPED SPARE LOCKNUTS IN DOOR SHIPMENT)
4. ALIGN THE SLOTS IN THE DOOR HINGE WITH THE STUDS ON THE HOUSING.
5. RE-ATTACH THE LOCKNUTS UNTIL THE NYLON SAFELY HOLDS THE NUT IN PLACE. DO NOT TIGHTEN FULLY. (SEE NEXT NOTE)
6. IMPORTANT: THE DOOR HINGE MUST MOVE FREELY ON THE STUDS IN HORIZONTAL AND VERTICAL DIRECTION. THIS ALLOWS THE DOOR TO CLEAR THE FLANGE ON OPEN AND CLOSE MOTION.
7. WITH DOOR IN PLACE, LET DOOR FALL IN SLOT TO CLEAR THE FLANGE AND CLOSE THE THE DOOR CAREFULLY.
8. USING THE PACKAGED FLAT HEAD SCREWS, FASTEN THE DOOR ONTO HOUSING. THE DOOR FLANGE WILL REST AGAINST CEILING SURFACE AROUND THE HOUSING FLANGE. (NYLON SCREW RETAINER WASHER IS ALSO INCLUDED TO KEEP THE SCREWS IN THE DOOR FRAMES WHEN UN-SCREWING TO OPEN THE DOOR)

	NAME	DATE	<div><b>CERTOLUX</b> SPECIALTY LUMINAIRES</div> <div>35 Oak St., Toronto, ON M9N 1A1 647-777-3300</div>					
Drawn								
Last Saved	roucet	4/22/2014						
Checked								
<p>UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGULAR: BEND ±1 ONE PLACE DECIMAL ±0.030 TWO PLACE DECIMAL ±0.015 THREE PLACE DECIMAL ±0.005</p>			ERP #:		IIS00035	REVISION:		01
			Title					
			Part Name:		IIS.-.3553.DOOR.INSTALL			
			Description:		VRIF 3553 DOOR INSTALLATION			
			MATERIAL:		FINISH:			
SIZE: A		SCALE:				SHEET 1 of 1		

UNLESS OTHERWISE SPECIFIED:  
 DIMENSIONS ARE IN INCHES  
 ANGULAR: BEND  $\pm 1$   
 ONE PLACE DECIMAL  $\pm 0.030$   
 TWO PLACE DECIMAL  $\pm 0.015$   
 THREE PLACE DECIMAL  $\pm 0.005$